



Abrasive Vacuum Recovery System (Model IND 200P ERL HD)



Owner's Manual

Date of Issue 24/08/2026 TSOM 329F

SurfacePrep UK
36 Orgreave Drive, Handsworth,
Sheffield,
South Yorkshire,
S13 9NR,

[Tel Sales: 0114 254 0600](tel:01142540600)
[TotalCare: 0114 254 1520](tel:01142541520)
www.surfaceprep.co.uk
HC.sales@surfaceprep.com
HC.totalcare@surfaceprep.com

**CE MACHINERY DIRECTIVE
(2006/42/EC)**



CE DECLARATION OF CONFORMITY

We HODGE CLEMCO LTD declare that the supplied equipment when installed and used in accordance with the owner's manual provided, conforms with the essential health and safety requirements of the above machinery directive

**UKCA LEGISLATION
(SUPPLY OF MACHINERY (SAFETY) REGULATIONS 2008 S.I. 2008:1597)**



UKCA DECLARATION OF CONFORMITY

We HODGE CLEMCO LTD declare that the supplied equipment when installed and used in accordance with the owner's manual provided, conforms with the essential health and safety requirements of the above UKCA legislation.

A handwritten signature in black ink, appearing to read 'Steven Staples'.

STEVEN STAPLES
Engineering Manager

A handwritten signature in black ink, appearing to read 'Harry Sampson'.

HARRY SAMPSON
Managing Director

MAINTENANCE INSPECTION CONTRACT

In response to numerous requests, we are now able to offer a Maintenance Inspection Contract for your Clemco Equipment.

These requests have been made by customers who appreciate the benefits of regular inspection/servicing on a planned basis. The remedial work that follows a breakdown or worse, the need for early equipment replacement due to accelerated wear may easily exceed the cost of a Maintenance Inspection Contract. If you would like further detail please contact our Customer Services Department on **0114 2548811**

A request for more information does not represent any form of commitment on your behalf, so can you afford to say 'NO' at this stage?

We look forward to hearing from you soon.

TABLE OF CONTENTS

COVER PAGE	1
MACHINERY DIRECTIVE/CE & UKCA DECLARATION OF CONFORMITY	2
TABLE OF CONTENTS	3
1.0 GENERAL DESCRIPTION	4
2.0 INSTALLATION INSTRUCTIONS	4-5
3.0 OPERATING INSTRUCTIONS	6-7
4.0 MAINTENANCE	8
SPARE PARTS LIST	9-10
ARRANGEMENT DIAGRAM: OVERALL ASSEMBLY	11
ARRANGEMENT DIAGRAM: VACUUM RECOVERY (IND 200PAERL)	12-13
ARRANGEMENT DIAGRAM: 200L SILO (IND 201C)	14
CONNECTION DETAILS FOR 110 & 240V SUPPLY	15
FLOOR HOPPER FOUNDATION DETAILS	16-17
TYPICAL AIRBORNE NOISE EMISSIONS EXPECTED	18
ADDENDUM I – ADDITION OF FLOOR HOPPER FLUIDISER	19
MAINTENANCE/SERVICE RECORD	20

1.0 GENERAL DESCRIPTION

This system is designed to recover spent recyclable abrasive from a blasting area into the silo for subsequent return to the connected blast machine. After depositing the abrasive into the silo/blast machine the vacuum flow containing air and dust continues to the vacuum unit, where the dust particles are removed by a high-performance polyester filter cartridge prior to air exhausting to the atmosphere.

Optional extras which can be supplied with this equipment includes:

- a) Larger floor hopper.
- b) Heavy duty floor gratings.
- c) Level sensor in storage silo - Standard on ERL version.
- d) Magnetic particle screen.
- e) Intermediate cyclone.
- f) Wall bush to facilitate alternative recovery by hose from work area direct to silo.
- g) EDB 90 Eductoblast head and regrader.
- h) EDBH 75 and EDBH 60 Eductoblast heads.

2.0 INSTALLATION INSTRUCTIONS

WARNING: All installation work must be carried out by suitable competent persons.

WARNING: Static Electricity can be generated during recovery operations; therefore the suction unit and silo must be suitably earthed, and only static conductive suction hoses must be used with this equipment.

WARNING: Under no circumstances must this unit be connected to an air supply of greater pressure than 7 Bar.

WARNING: It is essential that all hose couplings are secure and that any sealing gaskets are in good condition and in position. Escaping air at connections will reduce efficiency and can be dangerous.

Note: These instructions should be used in conjunction with those appropriate to the blast machine and safety protection equipment etc.

- 2.1 Position the floor hopper when supplied in the prepared concrete foundations. (See foundation plan).
- 2.2 Insert the suction nozzle into the bracket in the floor hopper.
- 2.3 Position the silo and blast machine to ensure that the suction nozzle points towards the silo inlet in a straight line. The two items must be securely connected and the seal between them in good condition. Anchor the blast machine to the floor where required.
- 2.4 Position the cyclone /regrader (when supplied) in close proximity to the silo/blast machine.

- 2.5 Cut the length of suction hose supplied to fit between suction nozzle, silo inlet/outlet (cyclone) and vacuum unit. At the blast machine connect a pressure equalising hose to the outlet of the RMS-2000 valve and to the appropriate silo connection elbow.
Note: It is important that the suction nozzle and the suction hose form a straight line (At app.30° to the vertical) to the silo inlet. Any curves or bends will reduce efficiency of the recovery and accelerate hose wear.
 - 2.6 Position the vacuum unit and cyclone (if supplied) and connect the vacuum hose to their respective spigots between silo(cyclone) and vacuum unit. Secure it by the hose clamps supplied. **Note: The length of hose can be reduced if required.**
 - 2.7 Ensure the vacuum unit dust drawer is in place and securely close the unit door.
 - 2.8 Connect an electrical supply to the control box on the suction unit.(110v/lph/50hz as standard, 240v/lph/50hz optional)
- Note: THIS UNIT MUST BE EARTHED.**
- 2.9 Securely connect a minimum 1" airline (25mm I.D.) to the suction unit ensuring that the airline is first purged of moisture. **Note: an air volume of 90 cfm (2.55m³/min) of clean dry compressed air to Pneurop 6611 is required.**
 - 2.10 Open the air shut off valve slowly to create the vacuum recovery.
 - 2.11 Increase the pressure regulator to provide sufficient vacuum to recover the abrasive.
Note: Elevated pressures may result in abrasive being carried over into the vacuum unit.
 - 2.12 Switch on the 110v electrical supply at the isolator. **Note: The cartridge is cleaned by the reverse air pulse cleaning mechanism every few seconds.**
 - 2.13 To stop the vacuum recovery, turn off the air shut off valve and switch off the electric supply isolator.
 - 2.14 **A)** Check the filter cartridge dust drawer for abrasive deposits. If there are any Present close the access door and reduce the air pressure regulator.
B) Check all seals on the unit to ensure they are in good working order.
 - 2.15 Fill the abrasive into the floor hopper (If supplied).
 - 2.16 If necessary readjust the airgap in the suction nozzle to achieve optimum rate of recovery by:
A) Loosening the 3 screws on the outer pipe.
B) Adjusting the inner pipe up or down (a few millimetres at a time) until the optimum recovery rate has been achieved.
B) Once optimum recovery rate has been established securely refasten the 3 screws.
 - 2.17 The system is now ready for operation.

3.0 OPERATING INSTRUCTIONS

WARNING: Under no circumstances must this unit be connected to an air supply of greater pressure than 7 Bar.

- 3.1. Open the air shut off valve on the vacuum unit slowly to create the desired vacuum recovery.
- 3.2. Adjust the pressure regulator until the correct setting is achieved. **Note: Minimum 5 bar (70 psi). Open the drain valve to produce a slight bleed of air.**
- 3.3. Open the small bypass valve to the inline filter which supplies the internal air receiver and subsequent reverse pulse cartridge cleaning.
- 3.4. Switch on the 110 v electrical supply.
- 3.5. Fill the floor hopper with abrasive and recover until the blast machine is full or until the silo level sensor is activated when abrasive recovery will stop. **Note: Do not overfill with abrasive.**

ESTIMATED ABRASIVE CAPACITY	
BLAST MACHINE	CAPACITY (LITRES)
1440	40
2040	90
2452	150
SILO	200
FLOOR HOPPER	80

AVERAGE WEIGHT OF ABRASIVE PER LITRE	
ABRASIVE	KG PER LITRE
ALUMINIUM OXIDE	1.85
GLASS BEAD	1.65
EXPENDABLE	2.00
AEROLYTE	0.80

- 3.6. Ensure that the reverse pulse cleaning system is operating correctly. The normal setting is one pulse every 30 seconds.
- 3.7. Regrader Adjustment (When fitted):

On these versions abrasive separation is controlled by adjustment of the knobs A & B on the regrader unit. The cyclone bin serves to collect any unwanted fines separated off at the regrader. It is advisable when introducing a new grade or type of media into the blast system to check the deposits in the bin and adjust the regrader accordingly.

3.7.1 Re-usable particles in cyclone bin:


3.7.2 At the regrader, unscrew knob 'A' anti clockwise one full turn then carefully screw knob 'B' clockwise until resistance is met. Do not over tighten as this will damage the deflector plate.

3.7.3 After the next blasting and recovery operation has been completed check the cyclone bin contents and repeat operation 3.7.2 until only unwanted fines are collected.

3.8. Unwanted fines returned to vacuum unit:

3.8.1 At the regrader, unscrew knob 'A' anti clockwise one full turn then carefully screw knob 'B' clockwise until resistance is met. Do not over tighten as this will damage the deflector plate.

3.8.2 Repeat operation 3.8.1 after each subsequent recovery operation until required level of fines removal is achieved.



IMPORTANT NOTICE: THE INLET DAMPERS ON THE CYCLONE SHOULD BE IN THE FULLY OPEN POSITION FOR MOST COMMON ABRASIVE TYPES AND GRADES. THESE DAMPERS ENABLE MORE FINITE SEPARATION TO BE ACHIEVED WHEN FINE GRADES OF LIGHTER MATERIAL IS BEING RECYCLED

4.0 MAINTENANCE

WARNING: *Ensure that the electricity supply is switched off at the isolator and the plug removed from the socket before any maintenance is carried out. Maintenance should only be carried out by trained and competent persons.*

WARNING: *Never inspect the dust compartment on the inside of the silo whilst smoking or allow any naked lights in their proximity. Dust concentrations can be combustible, explosive and hazardous to health, respiratory protection should be used.*

WARNING: *Never loosen or remove seals when abrasive is in the silo.*

4.1 Daily Programme

- 4.1.1 Empty the dust compartment in the vacuum unit. Emptying may be necessary more often than once a day depending on the volume of dust generated in the blasting operation.
- 4.1.2 With the silo empty remove and clean both abrasive outlet sieves on the silo and ensure they are correctly repositioned, and the access doors are securely closed.
- 4.1.3 Remove any debris from the floor hopper.

4.2 Weekly Programme

4.1.1 to 4.1.3 plus:

- 4.2.1 Check the seals on the silo and the suction unit. Replace leaking or worn seals.
- 4.2.2 Check that all hose connections and couplings are secure, and any gaskets required are in good condition and in place.
- 4.2.3 Remove waste particles from the two sieves in the silo.
- 4.2.4 Check seal or hoses between blast machines and silo outlets.
- 4.2.5 Check the filter cartridge in the vacuum unit. If dust layers are attached to the cartridge they should be cleaned off with a soft brush **Note: If these dust layers are difficult to remove from the filter cartridge, it can be the result of using a wet compressed air supply or because the dust generated in the blasting operation is excessively high.**



The filter cartridge should be removed and cleaned using a covered water supply. Ensure the cartridge is completely dry before reinstalling. If dust is emitted from the vacuum exhaust outlet the filter cartridge must be replaced with a new one immediately.
- 4.2.6 Check the security and condition of the compressed air supply hoses/fittings and pressure regulator. Also, the function of the reverse pulse valve and the in-line air filter.

SPARE PARTS LIST


ITEM	PART No.	DESCRIPTION
1	IND 201C	SILO 200 LITRE WITH LEVEL SENSOR
2	IND 200P AERL	RECOVERY UNIT ONLY /PNEUMATIC
3	MB 220E2 EHD	2" SUCTION NOZZLE
4	MB 220E2 D	FLOOR HOPPER COMPLETE WITH GRATING
5	HOSE 33	HOSE 2.5" H.D.RUBBER LINED
6	IND 10125	HOSE CLIP (73MM TO 79MM)
7	HC 4227 1	RECOVERY SYSTEM - OUTER CASING
8	IND 10582A	ACCOUSTIC FOAM
9	HC 4289	VENTURI PIPE
10	P 161	BACKNUT - 3/4" - M.I
11	P 99	BUSH 1.1/4" X 3/4" - M.I.
12	HC 4227 2	VENTURI MOUNTING
13	RCAMV 9	ADAPTOR 1/4" X 1/8"
14	P 157	BUSH 3/4" X 1/4"
15	P 158	ELBOW 3/4" M/F
16	P 156	TEE 3/4" FEM
17	IND 10015	DUST SEAL
18	HC 4292	SPIGOT
19	FAS M8 33A	SCREW 25 LONG
20	FAS M8 80A	WASHER
21	FAS M8 81A	SPRING WASHER
22	HC 4226 3	BLANKING PLATE
23	MB 10030	FILTER CARTRIDGE
24	FAS M10 13A	SCREW 40 LONG
25	FAS M10 81A	SPRING WASHER
26	FAS M10 83A	MUDWING WASHER
27	MB 10221	DUST DRAWER
28	CAB 151	TOGGLE CATCH
29	CAB 152	CATCH PLATE
30	RIVET 8	RIVET
31	XX MB SEAL	ACCESS DOOR SEAL
32	CAB 152 90	CATCH PLATE
33	IND 10578A	DIAPHRAGM VALVE (110V)
34	IND 10578	DIAPHRAGM VALVE (240V)
35	IND 10580	TIMER
36	HC 4280	FIXING BRACKET
37	FAS M6 11A	SCREW 16 LONG
38	FAS M6 81A	SPRING WASHER
39	P 181	BUSH 4" - 1"
40	KB 809	ADAPTOR PUSH IN ELBOW
41	RM 42	ADAPTOR FEM 1/4"
42	RCAMV 4	BULKHEAD ADAPTOR
43	CAP S26	ELBOW
44	P 151	ELBOW 4" F
45	P 152	NIPPLE 4"

ITEM	PART No.	DESCRIPTION
46	P 206	ELBOW 4" F
47	P 154	END CAP 4"
48	KB 911	TUBE PLASTIC
49	P 196	UNION ELBOW 1" M& F
50	P 190X	PRESSURE REGULATOR/FILTER
51	P 122	NIPPLE 1" X 3/4"
52	KB 11	PRESSURE GAUGE
53	P 26	ELBOW 1" M & F
54	P 58	TEE 1"
55	P 3	NIPPLE 1"
56	P 1	BALL VALVE 1"
57	BW 10	COUPLING 1" MALE
58	EC 100	EXTRACTOR/DRYER 15 CFM
59	IND 10352	ADAPTOR P.I.
60	P 228	BUSH 1" X 1/4"
61	MB 10090B	SOLENOID VALVE
62	MB 10090A	SOLENOID VALVE
63	HC 6861	SILO FABRICATION
64	HC 6601 2	SCREEN 4 MESH
	HC 6601	SCREEN 6 MESH
	HC 6601 3	0794F EXPAMET
65	HC 6861 3	DEBRIS DRAWER 4 MESH
	HC 6861 3A	6 MESH
	HC 6861 3B	0794F EXPAMET
66	BRLM HANDLE	HANDLE - PAIR
67	HC 6861 5	SILO LID
68	FAS M6 80A	WASHER
69	FAS M6 90A	NUT
70	HC 6861 4	DEFLECTOR PLATE - LINED
71	FAS M6 13A	SCREW 20 LONG
72	HC 6861 6	INLET CHUTE
73	FAS M12 80A	WASHER
74	FAS M12 91	NYLOC NUT
75	HC 6861 7	INLET SPIGOT
76	FAS M8 90A	NUT
77	HC 6861 2	SCREEN BRACKET
78	Z9	LEVEL SENSOR N.C.-CAPACITIVE
	Z8	LEVEL SENSOR N.C - INDUCTIVE
79	MB 10052A	SPIGOT
80	MB 10206	HOOK LOCK CLAMP
81	IND 10135C	CLAMPS FOR 200 LTR SILO - 20" +
82	IND 10135E	CLAMPS FOR 200 LTR SILO - 14"
83	FAS MB 13A	SCREW 16 LONG
84	HC 6598	SUPPORT LEGS FOR 52" HIGH MACHINES
	HC 6598 2	SUPPORT LEGS FOR 46" HIGH MACHINES
	HC 6598 3	SUPPORT LEGS FOR 40" HIGH MACHINES
85	MB 10052B	BLANKING PLATE

ARRANGEMENT OF IND 200P ERLHD RECOVERY UNIT





VACUUM RECOVERY UNIT




ABRASIVE SILO

ARRANGEMENT OF RECOVERY UNIT (IND200P AERL)






ARRANGEMENT OF 200 LITRE SILO (IND 201C)




STANDARD CONNECTION FOR 110V SUPPLY

CUSTOMER'S FUSED & ISOLATED
SUPPLY – 110V/1/50



OPTIONAL CONNECTION FOR 240V SUPPLY



CUSTOMER'S FUSED & ISOLATED
SUPPLY – 240V/1/50







FLOOR HOPPER FOUNDATION DETAILS

Customer responsible for:

- 1) Thickness and mix of concrete to suit site conditions.
- 2) Foundations to be waterproof.
- 3) All floor area around equipment to be flat and level.
- 4) Foundation walls to be perpendicular & parallel (-0mm +10mm)






TYPICAL AIRBORNE NOISE EMISSIONS EXPECTED

The following are readings taken from identical equipment operated under the conditions detailed below: The readings recorded should be used to determine the level of ear protection required by the operator(s) and personnel at risk





- Equipment Description : **IND 200P AERL**
- Location and Test Conditions : **Hodge Clemco Ltd Work Area**
- Power and Load Conditions : **110 PSI**



Position 1.6m high	Continuous		Test Duration	High Surge Reading		Back-ground Noise	Notes
	Max dBA	Min dBA		Max dBA	Period		
1. Operators Position	75		5 mins			65	
2. 1.6m(H) x 1m (Dist)	76		5 mins			65	
3. 1.6m(H) x 1m (Dist)	77		5 mins			65	
4. 1.6m(H) x 1m (Dist)	78		5 mins			65	
5. Position of any high surge	N/A	N/A	N/A	83	2 secs	67	N/A

ADDENDUM I – ADDITION OF FLOOR HOPPER FLUIDISER

The hopper fluidizer will provide a supply of air to the grit in the foundation pit hopper to assist grit recovery rates. As shown below, it is fed from the IND200P suction unit, this is then cable tied to the suction tube and inserted into the hopper. The tap coming out of the suction turns the fluidizer on and off and can be used to regulate the airflow. The specific parts can be found on drawings HC-5247 & HC-6872



MAINTENANCE / SERVICE RECORD

[illegible]